

9 CHASSIS CONCERNED

9-1	VEHICLE FRAME.....	9-1-1
9-1	VEHICLE FRAME.....	9-1-4
9-2	DRIVING CABIN.....	9-2-1
9-2	DRIVING CABIN.....	9-2-6
9-2	DRIVING CABIN.....	9-2-10
9-2	DRIVING CABIN.....	9-2-14
9-3	ENGINE ROOM.....	9-3-1
9-3	ENGINE ROOM.....	9-3-4
9-3	ENGINE ROOM.....	9-3-7
9-4	TILTING APPARATUS.....	9-4-1
9-5	DOOR WINDOW.....	9-5-1
9-6	LIFTING APPARATUS(ONE-TOUCH).....	9-6-1
9-7	FENDER(1.5mWIDTH).....	9-7-1
9-8	RETENTION WIRE.....	9-8-1
9-9	LIFTING APPARATUS.....	9-9-1
9-10	FENDER(1.3mWIDTH).....	9-10-1
9-11	LIFTING APPARATUS (MOWING EQUIPMENT, LIFTING LOCK MODEL).....	9-11-1
9-12	COUNTER WEIGHT.....	9-12-1

9-1 VEHICLE FRAME				Serial No.	9-1-2 001~035
.Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(10)	051-05080-000	Frame Assy,vehicle	1		001
1~(12)	051-05081-000	Frame Assy,vehicle	1		002~011
1~(12)	051-05081-100	Frame Assy,vehicle	1		012~
1	050-03910-100	Frame Assy,front	1		001
1	050-03911-100	Frame Assy,front	1	D	002~011
1	050-03911-200	Frame Assy,front	1	B	012~
2	050-03930-000	Frame Assy,rear	1		001
2	050-03931-000	Frame Assy,rear	1	D	002~011
2	050-03931-100	Frame Assy,rear	1	B	012~
3	614-4051-000	Pin	1		
4	613-0570-001	Pin	1		
5	054-0870-001	Nut	2		
6	054-0890-001	Spacer	2		
7	314-0820-001	Washer,lock	2		
8	054-0880-001	Cover	2		
9	053-19040-001	Protector	1		
10	054-12790-100	Stopper,turning	2		
11	054-12800-001	Shim (1)	2		
12	054-12810-001	Shim (2)	4		
13	613-3200-000	Pin	1		001
13	613-05020-000	Pin	1	D	002~
14	053-19590-001	Cover	1		002~011
(1)	BBA0451	Bearing,spherical	2		
(2)	LGL02	Nipple,grease	2		
(3)	79-G2649	Pin	1		
(4)	WS208	Washer,spring	8		
(5)	SBH11080251	Bolt	8		
(6)	SBH18160401	Bolt	4		
(7)	WS216	Washer,spring	4		
(8)	SBH14100251	Bolt	4		

9-1 VEHICLE FRAME				Serial No.	9-1-5 036~
Ilust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(11)	051-05081-200	Frame Assy,vehicle	1		036~045
1~(11)	051-05082-000	Frame Assy,vehicle	1	D	046~060
1~(11)	051-05083-000	Frame Assy,vehicle	1	D	061~
1	050-03911-300	Frame Assy,front	1		036~060
1	050-03913-000	Frame Assy,front	1	D	061~
2	050-03931-200	Frame Assy,rear	1		036~045
2	050-03932-000	Frame Assy,rear	1	D	046~
3	614-4051-000	Pin	1		
4	613-0570-001	Pin	1		
5	054-0870-001	Nut	2		
6	054-0890-001	Spacer	2		
7	314-0820-001	Washer,lock	2		
8	054-0880-001	Cover	2		
9	053-19040-001	Protector	1		
10	054-12790-200	Stopper,turning	2		
11	054-12800-001	Shim (1)	4		
12	054-12810-001	Shim (2)	4		
13	613-05020-000	Pin	1		
(1)	BBA0451	Bearing,spherical	2		
(2)	LGL02	Nipple,grease	2		
(3)	79-G2649	Pin	1		
(4)	WS208	Washer,spring	8		
(5)	SBH11080251	Bolt	8		
(6)	SBH18160401	Bolt	4		
(7)	WS216	Washer,spring	4		
(8)	SBH14100251	Bolt	4		
(9)	WS210	Washer,spring	6		
(10)	SBH14100201	Bolt	2		
(11)	WP116	Washer,plain	4		

9-2 DRIVING CABIN				Serial No.	9-2-2
					001~011
Ilust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(50)	710-04300-000	Driving cabin Assy	1		001
1~(58)	710-04301-000	Driving cabin Assy	1	D	002~
1	710-04131-000	Door (left)	1		001
1	710-04131-100	Door (left)	1	B	002~
2	710-04141-000	Door (right)	1		001
2	710-04141-100	Door (right)	1	B	002~
3	713-16450-000	H-rubber (front)	1		
4	713-15760-000	H-rubber (rear)	1		
5	719-2120-101	Visor	1		
6	714-16200-000	Bolt,stopper	2		
7	719-6660-101	Deadening	1		
8	718-5820-201	Cover right	1		
9	718-5830-201	Cover left	1		
10	719-5981-100	Stopper left	1		001
10	714-16520-000	Stopper left	1	D	002~
11	719-6430-100	Stopper right	1		001
11	714-16530-000	Stopper right	1	D	002~
12	713-16320-001	Floorboard 1	1		
13	714-15601-001	Floorboard 2	1		
14	712-08210-100	Floorboard 5	1		
15	713-16290-000	Cover 1,front	1		001
15	713-16291-000	Cover 1,front	1	D	002~
16	713-16270-000	Gasket	1		001
16	713-16271-000	Gasket	1	D	002~
17	713-16310-000	Floorboard 4	1		001
17	713-16311-000	Floorboard 4	1	D	002~
18	713-16300-000	Cover 2,front	1		001
18	713-16301-200	Cover 2,front	1	D	002~
19	710-04290-000	Cabin Assy	1		001
19	710-04291-000	Cabin Assy	1	D	002~

9-2 DRIVING CABIN				Serial No.	9-2-4
				001~011	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
(24)	73-A-100-1 special orders	Handle,outside (with key)	1		
(25)	73-A-100-2 special orders	Handle,outside	1		
(26)	TPS1125016	Screw	14		
(27)	69-KG-012	Bush	5		001
(27)	69-KG-012	Bush	1		002~
(28)	73-C-30-SG-14A	Grommet	1		001
(29)	73-AP-829-2	Handle	3		001
(29)	73-AP-829-2	Handle	2		002~
(30)	SBM8620	Screw	6		001
(30)	SBM8620	Screw	4		002~
(32)	01-21467-017	Rubber,cushion	2		
(33)	39-749300-000	Belt Assy,seat	1		
(34)	WS206	Washer,spring	48		001
(34)	WS206	Washer,spring	51		002~
(35)	SBH14060151	Bolt	28		001
(35)	SBH14060151	Bolt	47		002~
(36)	WS208	Washer,spring	36		001
(36)	WS208	Washer,spring	42		002~
(37)	SNH141210	Nut	4		
(38)	WS212	Washer,spring	10		
(39)	SNH140810	Nut	8		
(40)	WS210	Washer,spring	2		001
(40)	WS210	Washer,spring	4		002~
(41)	SNH141610	Nut	6		
(42)	WS216	Washer,spring	4		
(43)	SBH14080201	Bolt	16		001
(43)	SBH14080201	Bolt	22		002~
(44)	UBH14070255	Bolt	2		
(45)	SBM8614	Screw	16		
(46)	WP106	Washer,plain	4		

9-2 DRIVING CABIN				Serial No.	9-2-7 012~035	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks	
1~(58)	710-04302-100	Driving cabin Assy	1			
1	710-04131-200	Door left	1			
2	710-04141-200	Door right	1			
3	713-16450-000	H-rubber (front)	1			
4	713-15760-000	H-rubber (rear)	1			
5	719-2120-101	Visor	1			
6	714-16200-000	Bolt,stopper	2			
7	719-6660-101	Deadening	1			
8	718-5820-201	Cover right	1			
9	718-5830-201	Cover left	1			
10	714-16520-000	Stopper left	1			
11	714-16530-000	Stopper right	1			
12	713-16321-001	Floorboard 1	1			
13	714-15601-001	Floorboard 2	1			
14	712-08211-000	Floorboard 5	1			
15	713-16291-000	Cover 1,front	1			
16	713-16271-000	Gasket	1			
17	713-16312-000	Floorboard 4	1			
18	713-16301-400	Cover 2,front	1			
19	710-04293-000	Cabin Assy	1			
20	713-16370-000	Cover 2,rear	1			
21	713-16333-001	Floorboard 3	1			
22	713-16360-000	Trimming (ceiling)	1			
23	719-6160-001	Glass,rear	1			
(1)	72-HW97100101A	Heat glass,front	1			
(2)	76-4CS5461-B-L	Window left	1			
(3)	76-4CS5461-B-R	Window right	1			
(4)	34-N-712712	Seat Assy,driver	2			
(5)	39-7H1927-707	Belt Assy,outer	1			
(6)	39-7H1937-701	Belt Assy,inner	1			

9-2 DRIVING CABIN

Serial No.

9-2-9

012~035

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
(37)	SNH141210	Nut	4		
(39)	SNH140810	Nut	8		
(40)	WS210	Waser,spring	8		
(41)	SNH141610	Nut	6		
(42)	WS216	Washer,spring	4		
(43)	SBH14080201	Bolt	8		
(44)	SBM7420	Screw	4		
(45)	SBM8614	Screw	16		
(46)	WP106	Washer,plain	4		
(47)	SBH14100201	Bolt	4		
(48)	UWS207	Washer,spring	2		
(49)	WP110	Washer,plain	4		
(50)	SNH141020	Nut	2		
(51)	73-A-562	Handle,round bar	1		
(52)	73-A-562-P	Plate	1		
(53)	73-C-30-SG-42A	Grommet	2		
(54)	73-C-30-SG-28A	Grommet	1		
(55)	SBM7415	Screw	2		
(56)	69-KG-045	Bush	2		
(57)	69-KG-024	Bush	2		
(58)	69-KG-032	Bush	10		

9-2 DRIVING CABIN

Serial No.

036~065

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(58)	710-04302-200	Driving cabin Assy	1		036~039
1~(58)	710-04302-300	Driving cabin Assy	1	B	040~045
1~(59)	710-04302-400	Driving cabin Assy	1	B	046~
1	710-04131-200	Door left	1		
2	710-04141-200	Door right	1		
3	713-16450-000	H-rubber (front)	1		
4	713-15760-000	H-rubber (rear)	1		
5	719-2120-101	Visor	1		
6	714-16200-000	Bolt,stopper	2		
7	719-6660-101	Deadening	1		
8	718-5820-201	Cover right	1		
9	718-5830-201	Cover left	1		
10	714-16520-000	Stopper left	1		
11	714-16530-000	Stopper right	1		
12	713-16321-001	Floorboard 1	1		
13	714-15601-001	Floorboard 2	1		
14	712-08211-000	Floorboard 5	1		
15	713-16291-000	Cover 1,front	1		
16	713-16271-000	Gasket	1		
17	713-16312-000	Floorboard 4	1		
18	713-16301-400	Cover 2,front	1		
19	710-04293-100	Cabin Assy	1		036~039
19	710-04293-200	Cabin Assy	1	B	040~045
19	710-04293-300	Cabin Assy	1	B	046~
20	713-16370-000	Cover 2,rear	1		
21	713-16333-001	Floorboard 3	1		
22	713-16360-000	Trimming (ceiling)	1		
23	719-6160-001	Glass,rear	1		
24	714-20220-001	Spacer	2		045~055
(1)	72-HW97100101A	Heat glass,front	1		

9-2 DRIVING CABIN

Serial No.

036~065

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
(31)	SBM7410	Screw	2		
(32)	01-21467-017	Rubber,cushion	2		
(33)	39-749300-000	Belt Assy,seat	1		
(34)	WS206	Washer,spring	65		
(35)	SBH14060151	Bolt	61		
(36)	WS208	Washer,spring	28		
(37)	SNH141210	Nut	4		
(38)	WS212	Washer,spring	4		
(39)	SNH140810	Nut	8		
(40)	WS210	Waser,spring	8		
(41)	SNH141610	Nut	6		
(42)	WS216	Washer,spring	4		
(43)	SBH14080201	Bolt	8		
(44)	SBM7420	Screw	4		
(45)	SBM8614	Screw	16		
(46)	WP106	Washer,plain	4		
(47)	SBH14100201	Bolt	4		
(48)	UWS207	Washer,spring	2		
(49)	WP110	Washer,plain	4		
(50)	SNH141020	Nut	2		
(51)	73-A-562	Handle,round bar	1		
(52)	73-A-562-P	Plate	1		
(53)	73-C-30-SG-42A	Grommet	2		
(54)	73-C-30-SG-28A	Grommet	1		
(55)	SBM7415	Screw	2		
(56)	69-KG-045	Bush	2		
(57)	69-KG-024	Bush	2		
(58)	69-KG-032	Bush	10		
(59)	73-C-30-NG-79-O	Grommet	1		

9-2-15

9-2 DRIVING CABIN

Serial No.

066~

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(62)	710-04303-000	Driving cabin Assy	1		
1	710-04131-300	Door left	1		
2	710-04141-300	Door right	1		
3	713-16450-000	H-rubber (front)	1		
4	713-15760-000	H-rubber (rear)	1		
5	719-2120-101	Visor	1		
6	714-16200-000	Bolt,stopper	2		
7	719-6660-101	Deadening	1		
8	718-5820-201	Cover right	1		
9	718-5830-201	Cover left	1		
10	714-16520-000	Stopper left	1		
11	714-16530-000	Stopper right	1		
12	713-16321-001	Floorboard 1	1		
13	714-15601-001	Floorboard 2	1		
14	712-08211-000	Floorboard 5	1		
15	713-16291-000	Cover 1,front	1		
16	713-16271-000	Gasket	1		
17	713-16312-000	Floorboard 4	1		
18	713-16301-400	Cover 2,front	1		
19	710-04294-000	Cabin Assy	1		
20	713-16370-000	Cover 2,rear	1		
21	713-16333-001	Floorboard 3	1		
22	713-16360-000	Trimming (ceiling)	1		
23	719-6160-001	Glass,rear	1		
(1)	72-HW97100101A	Heat glass,front	1		
(2)	76-4CS5461-B-L	Window left	1		
(3)	76-4CS5461-B-R	Window right	1		
(4)	34-N-712712	Seat Assy,driver	2		
(5)	39-7H1927-707	Belt Assy,outer	1		
(6)	39-7H1937-701	Belt Assy,inner	1		

9-2 DRIVING CABIN

Serial No.

066~

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
(38)	WS212	Washer,spring	4		
(39)	SNH140810	Nut	8		
(40)	WS210	Waser,spring	8		
(41)	SNH141610	Nut	6		
(42)	WS216	Washer,spring	4		
(43)	SBH14080201	Bolt	8		
(44)	SBM7420	Screw	4		
(45)	SBM8614	Screw	16		
(46)	WP106	Washer,plain	4		
(47)	SBH14100201	Bolt	4		
(48)	UWS207	Washer,spring	2		
(49)	WP110	Washer,plain	4		
(50)	SNH141020	Nut	2		
(51)	73-A-562	Handle,round bar	1		
(52)	73-A-562-P	Plate	1		
(53)	73-C-30-SG-42A	Grommet	2		
(54)	73-C-30-SG-28A	Grommet	1		
(55)	SBM7415	Screw	2		
(56)	69-KG-045	Bush	2		
(57)	69-KG-024	Bush	2		
(58)	69-KG-032	Bush	10		
(59)	73-C-30-NG-79-O	Grommet	1		
(60)	79-NK-6N	Clip	3		
(61)	TPS1114010	Screw	37		
(62)	WS204	Washer,spring	34		

9-3 ENGINE ROOM				Serial No.	9-3-2 001~035
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(19)	790-01710-000	Engine room Assy	1		001
1~(19)	790-01711-000	Engine room Assy	1	D	002~011
1~(23)	790-01712-000	Engine room Assy	1	D	012~
1	790-01700-000	Engine room	1		001
1	790-01701-000	Engine room	1		002~011
1	790-01702-000	Engine room	1	D	012~
2	791-01631-000	Door left,side	1		001
2	791-01632-000	Door left,side	1	D	002~
3	791-01641-000	Door right,side	1		001
3	791-01642-000	Door right,side	1	D	002~
4	719-1980-001	Bracket,shovel	2		
5	624-0870-001	Washer	1		
6	719-5991-101	Seal,rubber	16		002~
(1)	1C-KP-200-50	Damper,stay	2		
(2)	WP706	Washer	12		
(3)	08-33210-20281	Cap	1		
(4)	19-SP123-11030	Pin	4		
(5)	KRE070	Ring,snap	4		
(6)	SBH14120351	Bolt	4		001
(7)	WS212	Washer,spring	6		
(8)	WP112	Washer,plain	6		
(9)	SNH141210	Nut	6		
(10)	PS3015	Pin,split	4		
(11)	SBH14120401	Bolt	6		001
(11)	SBH14120401	Bolt	8		002~
(12)	SNH140610	Nut	4		
(13)	WS206	Washer,spring	16		
(14)	SBH14060201	Bolt	4		
(15)	SBH14060151	Bolt	12		
(16)	SBH14100251	Bolt	1		

9-3 ENGINE ROOM				Serial No.	9-3-5
				036~078	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(23)	790-01712-100	Engine room Assy	1		
1~(23)	790-01712-200	Engine room Assy	1		
1~(23)	790-01713-000	Engine room Assy	1		
1	790-01702-100	Engine room	1		
1	790-01702-200	Engine room	1		
1	790-01703-000	Engine room	1		
2	791-01632-000	Door left,side	1		
3	791-01642-000	Door right,side	1		
4	719-1980-001	Bracket,shovel	2		
5	624-0870-001	Washer	1		
6	719-5991-101	Seal,rubber	16		
(1)	1C-KP-200-50	Damper,stay	2		
(2)	WP706	Washer	12		
(3)	08-32210-20281	Cap	1		
(4)	19-SP123-11030	Pin	4		
(5)	KRE070	Ring,snap	4		
(7)	WS212	Washer,spring	6		
(8)	WP112	Washer,plain	6		
(9)	SNH141210	Nut	6		
(10)	PS3015	Pin,split	4		
(11)	SBH14120401	Bolt	6		
(12)	SNH140610	Nut	4		
(13)	WS206	Washer,spring	16		
(14)	SBH14060201	Bolt	4		
(15)	SBH14060151	Bolt	12		
(16)	SBH14100251	Bolt	1		
(17)	WS210	Washer,spring	1		
(18)	WP110	Washer,plain	2		
(19)	92-27-115	Catch,bonnet	4		
(20)	SBH14080201	Bolt	10		

9-3 ENGINE ROOM				Serial No.	9-3-8
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(24)	790-01713-100	Engine room Assy	1		
1	790-01704-000	Engine room	1		
2	791-01632-000	Door left,side	1		
3	791-01642-000	Door right,side	1		
4	719-1980-001	Bracket,shovel	2		
5	624-0870-001	Washer	1		
6	719-5991-101	Seal,rubber	16		
7	793-08880-100	Stay,rear under mirror	1		
(1)	1C-KP-200-50	Damper,stay	2		
(2)	WP706	Washer	12		
(3)	08-32210-20281	Cap	1		
(4)	19-SP123-11030	Pin	4		
(5)	KRE070	Ring,snap	4		
(7)	WS212	Washer,spring	6		
(8)	WP112	Washer,plain	6		
(9)	SNH141210	Nut	6		
(10)	PS3015	Pin,split	4		
(11)	SBH14120401	Bolt	8		
(12)	SNH140610	Nut	4		
(13)	WS206	Washer,spring	16		
(14)	SBH14060201	Bolt	4		
(15)	SBH14060151	Bolt	12		
(16)	SBH14100251	Bolt	1		
(17)	WS210	Washer,spring	1		
(18)	WP110	Washer,plain	2		
(19)	92-27-115	Catch,bonnet	4		
(20)	SBH14080201	Bolt	10		
(21)	WS208	Washer,spring	14		
(22)	SNH140810	Nut	10		
(23)	WP108	Washer,plain	14		

9-4 TILTING APPARATUS				Serial No.	9-4-2 001~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(9)	882-00760-000	Tilting apparatus Assy	1		001
1~(9)	882-00760-100	Tilting apparatus Assy	1	B	002~011
1~(9)	882-00760-200	Tilting apparatus Assy	1	B	012~
1	613-1171-000	Pin	1		
2	884-0631-001	Spacer	1		
3	884-0660-001	Flange	1		
4	884-0640-001	Spacer	1		
5	613-1180-000	Pin	2		
6	880-0132-200	Frame,tilt	1		
6	880-0132-300	Frame,tilt	1		
6	882-00910-100	Frame,tilt	1		
(1)	BBA0601	Bush,spherical	1		
(3)	SBH11100251	Bolt	8		
(4)	SBH11100201	Bolt	4		
(5)	JAAN11NJ	Nut,bearing	1		
(6)	JWAW11NJ	Washer,bearing	1		
(7)	WS210	Washer,spring	12		
(8)	LGS02	Nipple,grease	2		
(9)	LGL02	Nipple,grease	1		

9-5 WINDOW(FOR DOOR)

Serial No.

001~

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~15	76-4CS5461-B-R	Window right	1		
1~15	76-4CS5461-B-L	Window left	1		
1	*	Frame,outer	1		
2	*	Frame,outer	1		
3A	76-4CS5461-2-3A	Glass (front)	1		
3B	76-4CS5461-2-3B	Glass (rear)	1		
5	*	Rubber,wind shield	1		
6	*	Rubber,wind shield	1		
7	76-4CS5461-2-7	Rubber,glass support	2		
8	*	Packing	8		
9	76-4CS5461-2-9	Groove	2		
10	*	Bushing,guide	8		
11	*	Packing,,waterproof	2		
12	76-4CS5461-2-12	Lock Assy	2		
13	*	Guard,water	1		
14	*	Rubber,support	2		
15	TPS1133008	Screw	3		

9-6 LIFTING APPARATUS (ONE-TOUCH)				Serial No.	9-6-2 001~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(14)	071-02140-000	Lifting apparatus Assy	1		001
1~(14)	071-02140-100	Lifting apparatus Assy	1	B	002~
1	072-03531-000	Link	1		
2	073-2980-001	Rod	2		
3	073-2961-100	Shaft (upper,right)	1		
4	073-2971-000	Shaft (upper,right)	1		
5	073-1630-000	Shaft (lower,left)	1		
6	073-1640-000	Shaft (lower,right)	1		
7	613-2991-000	Pin	6		
8	074-2970-001	Bush	2		
9	073-2950-001	Retainer	2		
10	613-1200-000	Pin	2		
11	072-03471-200	Frame,one-touch	1		001
11	072-04050-00	Frame,one-touch	1	D	002~
12	214-0230-001	Spring	4		
13	074-1520-001	Plate	4		
14	074-1700-001	Spacer	8		
(1)	SBH14120201	Bolt	8		
(2)	WS212	Washer,spring	8		
(3)	SBH14160351	Bolt	4		
(4)	SNH141610	Nut	4		
(5)	JK09NJ	Ball,steel	4		
(6)	LGS02	Nipple,grease	2		
(7)	LGL02	Nipple,grease	4		
(8)	SBA6080201	Bolt	8		
(9)	WS408	Washer,spring	8		
(10)	SBA6100201	Bolt	4		
(11)	WS410	Washer,spring	4		
(12)	SBH18160651	Bolt	4		
(13)	SNH181610	Nut	8		

9-7 FENDER (1.5mWIDTH)

Serial No.

001~

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(7)	722-01950-000	Fender Assy	1		001
1~(7)	722-01951-000	Fender Assy	1	D	002~011
1~(7)	722-01952-000	Fender Assy	1	D	012~029
1~(7)	722-01953-000	Fender Assy	1	D	030~065
1~(7)	722-01953-100	Fender Assy	1	B	066~
1	722-01910-000	Fender left,rear	1		001
1	722-01911-000	Fender left,rear	1	D	002~029
1	722-01912-000	Fender left,rear	1	D	030~065
1	722-01912-100	Fender left,rear	1	B	066~
2	722-01920-000	Fender right,rear	1		001
2	722-01921-000	Fender right,rear	1	D	002~029
2	722-01922-000	Fender right,rear	1	D	030~
3	722-01930-000	Fender left,front	1		001
3	722-01931-100	Fender left,front	1	D	002~011
3	722-01932-100	Fender left,front	1	D	012~029
3	722-01932-200	Fender left,front	1	B	030~
4	722-01940-000	Fender right,front	1		001
4	722-01941-000	Fender right,front	1	D	002~011
4	722-01942-100	Fender right,front	1	D	012~029
4	722-01942-200	Fender right,front	1	B	030~
(1)	SBH14100201	Bolt	26		001
(1)	SBH14100201	Bolt	24		002~
(2)	WS210	Washer,spring	26		001
(2)	WS210	Washer,spring	24		002~
(3)	SBH14080201	Bolt	10		
(4)	WS208	Washer,spring	10		
(5)	SNH140810	Nut	10		
(6)	WP108	Washer,plain	10		
(7)	WP110	Washer,plain	16		

9-8 RETENTION WIRE				Serial No.	9-8-2
					001~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(4)	072-03480-000	Retention wire Assy	1		
1~(4)	072-03481-000	Retention wire Assy	1		
1	074-3041-001	Wire	1		
2	074-3050-001	Bracket 1	1		
3	074-3050-000	Bracket 2	1		
4	074-3070-000	Bracket 3	1		
(1)	92-SC08	Straight shackle,stainless	1		
(2)	SBH14080201	Bolt	5		
(3)	WS208	Washer,spring	5		
(4)	WP108	Washer,plain	5		

9-9 LIFTING APPARATUS

Serial No.

9-9-2

002~

.llust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(8)	071-02070-000	Lifting apparatus Assy	1		002~045
1~(8)	071-02070-100	Lifting apparatus Assy	1	B	046~065
1~(8)	071-02070-200	Lifting apparatus Assy	1	B	066~
1	072-03450-000	Link lower	1		
2	613-1200-000	Pin	2		
3	613-1800-201	Pin	4		002~045
3	613-1800-201	Pin	2		046~065
3	613-1800-400	Pin	2		046~065
3	613-1800-501	Pin	4	B	066~
4	613-2991-000	Pin	4		
5	074-1700-001	Spacer	8		
6	074-2970-001	Bush	4		
(1)	08-46000-20560	Washer	6		
(2)	SNC2241	Nut,castle	4		
(3)	WP124	Washer,plain	4		
(4)	WS212	Washer,spring	6		
(5)	PS5045	Pin,split	4		
(6)	LGS02	Nipple,grease	4		
(7)	LGL02	Nipple,grease	4		
(8)	SBH14120201	Bolt	6		

9-10 FENDER(1.3mWIDTH)				9-10-2	
				Serial No.	002~
Ilust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(7)	722-02000-000	Fender Assy	1		002~011
1~(7)	722-02000-100	Fender Assy	1	B	012~035
1~(7)	722-02002-000	Fender Assy	1	D	036~065
1~(7)	722-02002-100	Fender Assy	1	B	066~
1	722-01960-100	Fender left,front	1		002~011
1	722-01960-200	Fender left,front	1	D	012~035
1	722-01961-100	Fender left,front	1	D	036~
2	722-01970-100	Fender right,front	1		002~011
2	722-01970-200	Fender right,front	1	D	012~035
2	722-01971-100	Fender right,front	1	D	036~
3	722-01980-000	Fender left,rear	1		002~035
3	722-01981-000	Fender left,rear	1	D	036~065
3	722-01981-100	Fender left,rear	1	B	066~
4	722-01990-000	Fender right,rear	1		002~035
4	722-01991-000	Fender right,rear	1	D	036~
5	724-01780-001	Stopper,slip	2		012~
(1)	SBH14100201	Bolt	24		002~011
(1)	SBH14100201	Bolt	27		012~
(2)	WS210	Washer,spring	24		002~011
(2)	WS210	Washer,spring	27		012~
(3)	SBH14080201	Bolt	10		
(4)	WS208	Washer,spring	10		
(5)	SNH140810	Nut	10		
(6)	WP108	Washer,plain	10		
(7)	WP110	Washer,plain	16		002~011
(7)	WP110	Washer,plain	19		012~

9-11 LIFTING APPARATUS (MOWING EQUIPMENT, LIFTING LOCK MODEL)				Serial No.	9-11-2
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(2)	073-04450-000	Lifting lock Assy	1		002~065
1~(2)	073-04450-100	Lifting lock Assy	1	B	066~
1	053-13210-000	Frame Assy,front	1		002~065
1	053-20060-100	Frame Assy,front	1	D	066~
2	072-03570-000	Link lower,lifting	1		
3	074-04850-000	Stopper	2		
4	614-05440-000	Pin	2		
(1)	92-K-15	Pin	4		002~065
(1)	79-G37	Pin	4	B	066~
(2)	WP133	Washer,plain	2		

9-12 COUNTER WEIGHT				9-12-2	
			Serial No.	001~	
Plust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(2)	053-20050-000	Counter weight Assy	1		001~065
1~(2)	053-20051-000	Counter weight Assy	1	D	066~
1	053-20040-000	Protector	1		001~065
1	053-20041-000	Protector	1	D	066~
(1)	SBH18160801	Bolt	4		001~065
(1)	SBH18161001	Bolt	4	D	066~
(2)	WS216	Washer,spring	4		