

6 CONTROL SYSTEM

6-1	FORWARD/BACKWARD CONTROL.....	6-1-1
6-2	OPERATING CONTROL(AUGER BRAKE).....	6-2-1
6-2	OPERATING CONTROL(AUGER BRAKE).....	6-2-3
6-3	OPERATING HYDRAULIC CONTROL.....	6-3-1
6-4	DISK CALIPER.....	6-4-1
6-5	FORWARD/BACKWARD CONTROL (LEVER/PEDAL SWITCHING MODEL).....	6-5-1
6-6	OPERATING HYDRAULIC CONTROL (MECHANICAL JOY-STICK MODEL).....	6-6-1
6-7	OPERATING HYDRAULIC CONTROL(ANGLING BLADE).....	6-7-1
6-8	OPERATING HYDRAULIC CONTROL(MULTI BLADE).....	6-8-1

6-1 FORWARD/BACKWARD CONTOROL				6-1-2	
				Serial No.	001~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(12)	552-00870-100	Forward/backward control Assy	1		
1	554-02720-001	Rod	1		
2	553-03171-001	Link	1		
3	552-00781-000	Bracket	1		
(1)	85-A-QHB-B19	Potentiometer	1		
(2)	RBL0510	Joint,ball	1		
(3)	RBL0511	Joint,ball	1		
(4)	SNH140511	Nut	1		
(5)	SNH340510	Nut	1		
(6)	SNH340610	Nut	1		
(7)	SNH140510	Nut	3		
(8)	SBH14060201	Bolt	2		
(9)	WS206	Washer,spring	3		
(10)	SBM8408	Screw(+)	2		
(11)	WS205	Washer,spring	2		
(12)	WS204	Washer,spring	2		

6-2 OPERATING CONTROL (AUGER BRAKE)				6-2-2	
				Serial No.	001
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(16)	421-00850-000	Operating control Assy	1		
1	424-2031-101	Adapter	1		
2	424-02100-001	Adapter	1		
3	432-02460-200	bracket	1		
(1)	39-DB-2008-K-WS	Caliper,disk	1		
(2)	19-ED3P-02T-24V-00	Valve,solenoid	1		
(3)	29-2103-01-41.00	Coupling	1		
(4)	SBH14120251	Bolt	4		
(5)	HNL0220400	Nipple	1		
(6)	2P-1071-04	Elbow	2		
(7)	HNL0720400	Tee	1		
(8)	2P-4043-06-04-N	Adapter	1		
(9)	H05051041600P	Hose	1		
(10)	H05051040700P	Hose	1		
(11)	HA1404	Adapter	1		
(12)	HA1504	Adapter	2		
(13)	H05051041400P	Hose	1		
(14)	WP512	Washer,plain	4		
(15)	SBH14060401	Bolt	2		
(16)	WS206	Washer,spring	2		

6-2 OPERATING CONTROL (AUGER BRAKE)				Serial No.	6-2-4 002~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(17)	421-00850-100	Operating control Assy	1		002~045
1~(17)	421-00850-200	Operating control Assy	1	B	046~
1	424-2031-101	Adapter	1		
2	423-02470-000	Bracket	1		
3	432-02460-200	Bracket	1		
(1)	39-DB-2008-K-WS	Caliper,disk	1		
(2)	19-ED3P-02T-24V-00	Valve,solenoid	1		
(3)	29-2103-01-53.00	Coupling	1		
(4)	SBH11120251	Bolt	4		
(5)	2P-2088-02-04-N	Elbow	1		
(6)	2P-1071-04	Elbow	2		
(7)	2Q-FPD12673	Tee	1		
(9)	H05051041800P	Hose	1		
(10)	H05051040500P	Hose	1		
(11)	HA1404	Adapter	2		
(12)	HA1504	Adapter	1		
(13)	H05051041400P	Hose	1		
(14)	WP512	Washer,plain	4		
(15)	SBH14060451	Bolt	2		
(16)	WS206	Washer,spring	2		
(17)	2P-1067-04	Connector	1		

6-3 OPERATING HYDRAULIC CONTOROL				Serial No.	6-3-2 001~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(8)	582-01950-000	Operating hydraulic control Assy	1		001~011
1~(8)	582-01950-100	Operating hydraulic control Assy	1	B	012~
1	583-0960-000	Lever	1		
2	583-0551-000	Lever	1		
3	583-0532-000	Lever	3		
4	583-0542-000	Lever	3		
5	584-0630-200	Knob lifting	1		
6	584-0750-200	Knob tilting	1		
7	584-0760-200	Knob tipping	1		
8	584-0770-200	Knob blower case revolving	1		
9	584-0640-200	Knob turning	1		
10	584-0650-200	Knob cap	1		
11	584-0781-100		1		
12	584-0790-200		1		
(1)	12-92702-06351	Bolt	2		
(2)	12-94311-05082	Washer	24		
(3)	92-5mm width	Pin	24		001~011
(3)	12-93601-12082	Pin,split	24	B	012~
(4)	12-92601-06181	Bolt	14		
(5)	12-21011-33307	Pin	24		
(6)	12-21011-31507	Link	8		
(7)	12-21011-31205	Bracket	8		
(8)	SNH140810	Nut	8		

6-4 DISK CALIPER

Serial No.

001~

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~9	39-DB-2008-K-WS	Caliper,disk Assy	1		
1	*	Cylinder	2		
2	39-CS08-002	Piston	2		
3	*	Packing	2		
4	*	Seal,dust	2		
5	39-CS08-008A	Pad kit	1		
	*	Pad	2		
	*	Spring	1		
6	39-CS08-005	Bleeder	1		
7	*	Nipple	3		
8	39-CS08-007	Pipe (include #7)	1		
9	*	Ring,dust seal	2		
3,4,9	39-CS08-A01	Seal kit	1		

6-5 FORWARD/BACKWARD CONTROL (LEVER/PEDAL SWITCHING MODEL)				Serial No.	6-5-2 001~	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks	
1~(35)	551-00640-000	Forward/backward control Assy	1		001~045	
1~(34)	551-00640-100	Forward/backward control Assy	1	B	046~	
1	552-00911-000	Bracket	1			
2	554-02610-001	Bracket	1			
3	553-2760-001	Bracket,lever	1			
4	553-2901-001	Lever	1			
5	554-02620-001	Link	1			
6	553-2921-000	Link	1			
7	554-0790-001	Knob	1			
8	554-2310-001	Rod	1			
9	554-2320-100	Stopper	1			
10	554-2330-001	Spacer	1			
11	324-0010-201	Bolt,set	2			
12	748-7670-001	Unit,control	1			
13	779-0340-001	Nameplate	1			
14	779-0412-001	Nameplate	1			
(1)	85-A-QHB-B19	Potentiometer	1			
(2)	6K-MC9Z-KF3	Lenz	1			
(3)	6K-MC9Z-3DB	Screen	2			
(4)	6K-LFTD-2AP	LED bulb	2			
(5)	6K-LFTD-2GP	LED bulb	2			
(6)	41-X-10GQ22-B	Switch	2			
(7)	73-C-91-3	Catch,magnet	1			
(8)	92-L20	Conical	8			
(10)	DU2030	Bush	1			
(11)	KRE030	Ring,snap	1			
(13)	RBL0510	Joint,ball	1			
(14)	RBL0511	Joint,ball	1			
(15)	SBH11060201	Bolt	4			
(16)	SNH140511	Nut	1			

6-6 OPERATING HYDRAULIC CONTROL (MECHANICAL JOY-STICK MODEL)				Serial No.	6-6-2 001~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(25)	581-00920-000	Operating hydraulic control Assy	1		001~011
1~(25)	581-00920-100	Operating hydraulic control Assy	1	B	012~045
1~(25)	581-00920-200	Operating hydraulic control Assy	1	B	046~065
1~(25)	581-00920-300	Operating hydraulic control Assy	1	B	066~
1	584-0760-200	Knob tipping	1		
2	584-0790-200	Knob raising and lowering	1		
3	584-0110-001	Bracket	6		
4	604-0440-200	Crevice	4		001~065
4	604-00840-000	Crevice	4	D	066~
5	604-0501-100	Crevice	2		001~065
5	604-00850-000	Crevice	2	D	066~
6	584-2860-001	Link	12		
7	584-2870-001	Shaft	1		
8	583-2160-000	Lever raising and lowering	1		
9	583-2170-000	Lever tipping	1		
10	713-11781-000	Cover,front	1		001~011
10	713-17140-000	Cover,front	1	D	012~
11	719-6490-001	Deadening	1		
12	718-6310-001	Clamp	1		001~011
12	713-19360-001	Clamp	1	D	012~
13	732-03600-200	Cover	1		001~011
13	732-03600-300	Cover	1	B	012~
14	776-2822-001	Nameplate	1		
15	773-3150-001	Nameplate	1		
16	583-02330-001	Joy-stick	1		
14	774-12150-001	Nameplate	1		
18	774-12160-001	Nameplate	1		
19	774-12170-001	Nameplate	1		
20	733-06900-000	Panel Assy	1		
(1)	12-21011-33307	Pin	24		

6-7-2

6-7 OPERATING HYDRAULIC CONTROL
(ANGLING BLADE)

Serial No.

002~

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(8)	582-01970-000	Operating hydraulic control Assy	1		
1	583-0960-000	Lever	1		
2	583-0551-000	Lever	1		
3	583-0532-000	Lever	3		
4	583-0542-000	Lever	3		
5	584-0630-200	Knob lifting	1		
6	584-1210-100	Knob tilting,blade	1		
7	584-0760-200	Knob tipping	1		
8	584-0770-200	Knob blower case revolving	1		
9	584-0640-200	Knob turning	1		
10	584-0650-200	Knob cap	1		
11	584-0781-100	Knob expansion and contraction	1		
12	584-0790-200	Knob raising and lowering	1		
(1)	12-92702-06351	Bolt	2		
(2)	12-94311-05082	Washer	24		
(3)	92-5mm width	Pin	24		
(4)	12-92601-06181	Bolt	14		
(5)	12-21011-33307	Pin	24		
(6)	12-21011-31507	Link	8		
(7)	12-21011-31205	Bracket	8		
(8)	SNH140810	Nut	8		

6

6-8 OPERATING HYDRAULIC CONTOROL (MULTI BLADE)				6-8-2	
				Serial No.	
				046~	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(8)	582-01980-000	Operating hydraulic control Assy	1		
1	583-0960-000	Lever	1		
2	583-0551-000	Lever	1		
3	583-0532-000	Lever	3		
4	583-0542-000	Lever	3		
5	584-0630-200	Knob lifting	1		
6	584-1690-100	Knob tilting,blade left	1		
7	584-0760-200	Knob tipping	1		
8	584-2900-200	Knob blower case rev.,blade right	1		
9	584-0640-200	Knob turning	1		
10	584-0650-200	Knob cap	1		
11	584-0781-100	Knob expantion and contraction	1		
12	584-0790-200	Knob raising and lowering	1		
(1)	12-92702-06351	Bolt	2		
(2)	12-94311-05082	Washer	40		
(3)	12-93601-12082	Pin	24		
(4)	12-92601-06181	Bolt	14		
(5)	12-21011-33307	Pin	24		
(6)	12-21011-31507	Link	8		
(7)	12-21011-31205	Braket	8		
(8)	SNH140810	Nut	8		