

5 DRIVING SYSTEM

5-1	DRIVING SYSTEM.....	5-1-1
5-2	STEERING CYLINDER.....	5-2-1

5-1 DRIVING SYSTEM				5-1-2	
			Serial No.	069~	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(42)	510-00452-300	Driving system Assy	1		
1	513-1890-201	Bracket	1		
3	513-1330-100	Cover	2		
4	613-1360-100	Pin	4		
(1)	2Y-IS-070314	Cylinder,steering	2		
(2)	29-DT04303A007A	Filter Assy	1		
(3)	08-43415-60021A	Wheel,steering	1		
(4)	29-S159-2-0A000230CA1A	Unit,steering	1		
(5)	29-SPA-1C1145A	Valve,flow priority	1		
(6)	2P-1069-08-06-70A-N	Elbow	1		
(7)	H05053061500P	Hose	1		
(8)	2P-1034-08-06-N	Elbow	2		
(9)	5K-20491-104000	Shaft Assy,column	1		
(10)	2Q-FPD13658..1	Elbow,check	1		
(11)	2P-1065-04	Connector	1		
(12)	H05053041500P	Hose	1		
(13)	2Q-FPD13658..1	Elbow,check	1		
(17)	H05051061100P	Hose	2		
(18)	2L-WEP-1-311H	Elbow	3		
(19)	H05053062200P	Hose	1		
(21)	HA1406	Adapter	4		
(22)	HNL0720800	Tee	2		
(23)	HNL0220600	Nipple	2		
(24)	2P-1060-06	Elbow,swivel	2		
(25)	H02053061450P	Hose	2		
(27)	SBH14080601	Bolt	2		
(28)	SBH11100301	Bolt	3		
(29)	SNH181010	Nut	3		
(30)	SNH341420	Nut	2		
(31)	SBH11100351	Bolt	4		

5-2 STEERING CYLINDER			Serial No.	069~	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~18	2Y-IS-070314	Cylinder Assy	1		
1	*	Tube,cylinder	1		
2	2Y-IS-070314RC	Rod comp,piston (include #16)	1		
3	2Y-IS-070314-3	Head,cylinder (include #5)	1		
4	2Y-IS-070314-4	Piston	1		
5	2Y-IS-070314-5	Bush,rod	1		
6	2Y-IS-070314-6	U-nut	1		
7	2Y-IS-070314-7	Seal,dust	1		
8	2Y-IS-070314-8	Ring,snap	1		
9	2Y-IS-070314-9	O-ring	1		
10	2Y-IS-070314-10	O-ring	1		
11	2Y-IS-070314-11	Ring,back-up	1		
12	2Y-IS-070314-12	Packing,rod	1		
13	2Y-IS-070314-13	Ring,back-up	1		
14	2Y-IS-070314-14	Packing,piston	1		
15	2Y-IS-070314-15	Ring,slide	2		
16	2Y-IS-070314-16	Bush	2		
17	2Y-IS-070314-17	Nipple,grease	2		
18	2Y-IS-070314-18	Nipple,grease	1		
	2Y-IS-070314RA	Rod Assy,piston (#2~16)	1		
	2Y-5030-3	Seal kit (#7,9~15)	1		