

## 4 BRAKE SYSTEM

4-1	FOOT BRAKE.....	4-1-1
4-2	HYDRAULIC SERVO MASTER.....	4-2-1
4-3	BRAKE.....	4-3-1
4-4	HAND BRAKE.....	4-4-1
4-5	BRAKE HEAD.....	4-5-1



4-1 FOOT BRAKE PIPING				4-1-2	
				Serial No. 069~	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(39)	530-01501-400	Foot brake piping Assy	1		
1	532-01940-000	Pedal,brake	1		
2	533-08530-201	Shaft	1		
3	533-09270-100	Link (1)	1		
4	533-09240-100	Link (2)	1		
5	533-08522-000	Link (3)	1		
6	644-0100-101	Spring	1		
7	324-00150-000	Bolt,set	1		
9	534-06350-101	Rod	1		
10	534-06620-001	Rod	1		
11	533-05890-101	Bracket	1		
13	534-05690-001	Plate,rubber	1		
14	533-09260-200	Pipe (front 1)	1		
15	533-09041-100	Pipe (rear 1)	1		
16	533-09251-100	Pipe (rear 2)	1		
17	533-08441-100	Pipe (axle 1)	2		
18	533-08451-100	Pipe 'axle 2)	2		
19	534-0850-100	Connector,three way	2		
20	534-06060-000	Clamp	2		
22	714-16171-001	Seat	1		
23	533-09420-000	Bracket	1		
(1)	3H-326-000-50051	Master,hydro servo	1		
(2)	3H-399-000-11300	Reservoir Assy,oil	1		
(3)	00-46431-58000	Cover,pedal	1		
(4)	UB02205	Unit,bearing	2		
(5)	UB02206	Unit,bearing	2		
(6)	41-D4MC-5020	Switch	1		
(7)	59-HS12	Joint,spherical	1		
(8)	35-RBM12	Joint,spherical	2		
(9)	35-RBML12	Joint,spherical	2		



## 4-2 HYDRO SERVO MASTER

Serial No.

069~

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~6	3H-326-000-50051	Hydro servomaster Assy	1		
1	3H-327-000-10041	Hydro servo	1		
2	3H-322-000-27010	Cylinder,tandem master	1		
3	3H-3001-1030	Bolt	2		
4	3H-3021-0010	Washer,spring	3		
5	3H-415-116-90010	Stad	1		
6	3H-3016-0010	Nut	1		
	3H-327-900-10040	Repair kit,hydro servo	1		
	3H-322-900-27010	Repair kit,master cylinder	1		

4-3 BRAKE				4-3-2	
				069~	
Serial No.					
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~32	36-11755-2022	Brake Assy	1		
1~4	36-G102-00650	Shoe Assy	2		
1	*	Shoe	2		
2	*	Lining	2		
3	36-BA40-0505	Rivet	32		
4	36-BA40-0103	Bushing	2		
5	36-G200-19300	Cylinder Assy,wheel	1		
6~13	36-B227-053A	Cover Assy	1		
6	*	Spring	2		
7	*	Washer	2		
8	*	Spindle	2		
9	*	Bracket	1		
10	*	Pin	2		
11	*	Cover	1		
12	*	Cam,adjuster	2		
13	*	Rivet	9		
14	36-BA40-0114	Clip	2		
15	36-BA40-0121	Washer	8		
16	36-B217-051	Pin,anchor	2		
17	36-B217-071	Clip	2		
18	36-B217-091	Pin	2		
19	36-B217-101	Nut	2		
20	36-B217-121	Cover	1		
21	36-B217-131	Cover	2		
22	36-B217-141	Bolt	2		
23	36-B217-151	Spring	1		
24	36-01034-1032	Bolt	2		
25	36-02052-1815	Nut	2		
26	36-02122-0806	Nut	2		
27	36-02152-1210	Nut	2		



## 4-4 HAND BRAKE

Serial No.

069~

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(13)	571-00460-000	Hand brake Assy	1		
1	604-0510-000	Crevice	1		
(1)	39-BM45-101-020-00	Parking brake	1		
(2)	90-419-2221/d	Head Assy,brake	1		
(3)	41-X-10GQ-B	Switch	1		
(4)	PS2016	Pin,split	1		
(5)	RBL0810	Ball,link	1		
(6)	WP108	Washer,PLAIN	1		
(7)	73-C-30-SG-50A	Grommet	1		
(8)	SBH14080251	Bolt	2		
(9)	SNH140810	Nut	5		
(10)	WS208	Washer,spring	4		
(11)	79-36150-20064KAI	Cable	1		
(12)	19-SP123-30828	Pin	1		
(13)	CC0229	Clamp	1		



4-5 BRAKE HEAD				4-5-2	
			Serial No.	001~	
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~21	90-419-2221/d	Brake head Assy	1		
1	90-4-2015	Plate,torque	1		
2	90-4-2025	Plate,torque	1		
3	90-54-2006	Sleeve	2		
4	90-43-8886	Bolt,adjust	1		
5	*	Lining,brake	2		
6	*	Spring	1		
7	*	Cam	2		
8	*	Retainer,ball	1		
9	*	Ball,bearing	3		
10	*	ID seal	1		
11	*	Boots	1		
12	90-83-2010	Lever	1		
13	*	Bearing,thrust	1		
14	90-43-9060	Washer,plain (stainless)	1		
15	90-80-7836	Washer,plain	1		
16	90-63-611	Nut,adjust	1		
17	90-63-7631	Nut,jam	1		
18	90-111-2013	Bushing	8		
19	90-63-508	Nut	2		
20	*	Boots	2		
21	90-43-8890	Bolt,mounting	2		
	90-304-2221	Brake repair KIT	1		
	90-304J7024	Ball,cam kit	1		
	90-328-2845	Pad kit (#5)	1		