

5 DRIVING SYSTEM

5-1	DRIVING SYSTEM.....	5-1-1
5-1	DRIVING SYSTEM.....	5-1-4
5-2	STEERING CYLINDER.....	5-2-1
5-2	STEERING CYLINDER.....	5-2-3

5-1 DRIVING SYSTEM				Serial No.	5-1-2	
				001		
Illust No.	Part No.	Part Name	QTY	CONV	Remarks	
1~(37)	510-00460-000	Driving system Assy	1			
1	513-1890-001	Bracket	1			
2	514-1530-000	Shaft,column	1			
3	513-1330-100	Cover	2			
4	613-1360-100	Pin	4			
5	514-01910-001	Tee	1			
(1)	1C-60630-45700..4	Cylinder	2			
(2)	29-DT04303A007A	Filter Assy	1			
	29-PXE3300S014A	Element	1			
(3)	08-43415-60021A	Steering wheel	1			
(4)	29-S159-2-0A000230CA10	Steering unit	1			
(5)	29-SPA-1C1145A	Valve,flow priority	1			
(6)	2P-1069-08-06-70A-N	Elbow	1			
(7)	H05053061800P	Hose	1			
(8)	2P-1034-08-06-N	Elbow	2			
(9)	H05051062050P	Hose	1			
(10)	2Q-FPD13658..1	45° Elbow,check	1			
(11)	2P-1065-04	Adapter	1			
(12)	H05053041450P	Hose	1			
(13)	2Q-FPD12798	Elbow,check	1			
(14)	HA0606	Adapter	1			
(15)	WS210	Washer,spring	7			
(16)	JLKC06	Joint,swivel	1			
(17)	H05051060950P	Hose	1			
(18)	2L-WEP-1-311H	45° Elbow	3			
(19)	H05053062500P	Hose	2			
(20)	HA1006	Adapter	1			
(21)	HA1406	Adapter	4			
(22)	HNL0720600	Tee	1			
(23)	HNL0220600	Nipple	2			

5-1 DRIVING SYSTEM				5-1-5	
				Serial No.	002~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~(37)	510-00461-000	Driving system Assy	1		002~011
1~(37)	510-00461-100	Driving system Assy	1	B	012~035
1~(37)	510-00461-200	Driving system Assy	1	B	036~045
1~(37)	510-00462-000	Driving system Assy	1	D	046~065
1~(37)	510-00462-100	Driving system Assy	1	B	066~082
1~(37)	510-00462-200	Driving system Assy	1	B	083~
1	513-1890-001	Bracket	1		002~045
1	513-1890-101	Bracket	1	B	046~065
1	513-1890-201	Bracket	1	B	066~
2	514-1530-000	Shaft,column	1		002~045
3	513-1330-100	Cover	2		
4	613-1360-100	Pin	4		002~011
4	613-05080-000	Pin	4	B	012~
5	514-01910-001	Tee	1		002~035
(1)	1C-60630-45700..4	Cylinder,steering	2		002~011
(1)	2Y-IS-070314	Cylinder,steering	2	B	012~
(2)	29-DT04303A007A	Filter Assy	1		
	29-PXE3300S014A	Element	1		
(3)	08-43415-60021A	Steering wheel	1		
(4)	29-S159-2-0A000230CA10	Steering unit	1		
(5)	29-SPA-1C1145A	Valve,flow priority	1		
(6)	2P-1069-08-06-70A-N	Elbow	1		
(7)	H05053061500P	Hose	1		
(8)	2P-1034-08-06-N	Elbow	2		
(9)	H05071061800P	Hose	1		
(10)	2Q-FPD13658..1	45° Elbow,check	1		
(11)	2P-1065-04	Adapter	1		
(12)	H05053041450P	Hose	1		
(13)	2Q-FPD12798	Elbow,check	1		
(14)	HNL0920600	Cross	1		036~045

5-2 STEERING CYLINDER				5-2-2	
				Serial No.	001~011
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~16	1C-60630-45700	Cylinder Assy	1		
1	1C-60632-45701	Tube Assy,cylinder	1		
2	1C-60632-36902	Rod Assy,cylinder	1		
3	1C-60121-50102	Head,cylinder	1		
4	1C-301361-03003	Bush	1		
5	1C-60911-30015	U-ring	1		
6	1C-60461-03001	Ring,back-up	1		
7	1C-30191-30060	Ring,wiper	1		
8	1C-95122-04500	O-ring	1		
9	1C-95723-04500	Ring,back-up	1		
10	1C-95151-05000	O-ring	1		
11	1C-60221-50104	Piston	1		
12	1C-60161-50011	Seal	1		
13	1C-60181-50031	Ring,slide	2		
14	1C-96131-20103	Nipple,grease	2		
15	1C-96121-20103	Nipple,grease	1		
16	1C-60421-25330	Bush	2		
5~10 12,13	1C-60639-28901	Seal kit	1		

5-2 STEERING CYLINDER				5-2-4	
				Serial No.	012~
Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1~18	2Y-IS-070314	Cylinder Assy	1		
1	*	Tube,cylinder	1		
2	2Y-IS-070314RC	Rod comp,piston (include #16)	1		
3	2Y-IS-070314-3	Head,cylinder (include #5)	1		
4	2Y-IS-070314-4	Piston	1		
5	2Y-IS-070314-5	Bush,rod	1		
6	2Y-IS-070314-6	U-nut	1		
7	2Y-IS-070314-7	Seal,dust	1		
8	2Y-IS-070314-8	Ring,snap	1		
9	2Y-IS-070314-9	O-ring	1		
10	2Y-IS-070314-10	O-ring	1		
11	2Y-IS-070314-11	Ring,back-up	1		
12	2Y-IS-070314-12	Packing,rod	1		
13	2Y-IS-070314-13	Ring,back-up	1		
14	2Y-IS-070314-14	Packing,piston	1		
15	2Y-IS-070314-15	Ring,slide	2		
16	2Y-IS-070314-16	Bush	2		
17	2Y-IS-070314-17	Nipple,grease	2		
18	2Y-IS-070314-18	Nipple,grease	1		
	2Y-IS-070314RA	Rod Assy,piston (#2~16)	1		
	2Y-5030-3	Seal kit (#7,9~15)	1		