3 ACCELERATOR CONCERNED

3-1 POWER HYDRAULIC OIL PIPING 3-1-1

3-2 TRAVELING POWER AND APPARATUS 3-2-1

3-3 PROPELLER SHAFT 3-3-1

3-4 PROPELLER SHAFT 3-4-1

3-5 PROPELLER SHAFT 3-5-1

3-6 SUSPENSION 3-6-1

3-7 LEAF SPRING 3-7-1

3-8 SHOCK ABSORBER 3-8-1

3-9 AXLE 3-9-1

3-10 DIFFERENTIAL GEAR 3-10-1

3-11 BRAKE CALIPER (Front) 3-11-1

3-12 BRAKE CALIPER (Rear) 3-12-1

3－1 POWER HYDRAULIC OIL PIPING

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～(87)	080-00681-000	Power oil line group Assy	1		
1	083-2660-000	Block, piping	1		
2	081-0451-000	Tank, power oil	1		
3	084-2590-101	Clamp,hose	1		
5	024-0120-001	Packing, copper	1		
6	024-0570-001	Plug, drain	1		
7	084-0880-001	Clamp	1		
(1)	10-PV100-666ED	Pump	1		
(2)	19-ICV-08RC-17	Valve, check	1		
(3)	10-PV100-665ED	Pump	1		
(4)	10-SC1-00188	Motor	2		
(5)	6E-C3-108-4	Heater, oil tank	1		
(6)	3E-HMK04-A-00N-09#05-A	Filter Assy	1		
(7)	10-SC4876	Filter Assy	1		
(8)	22-NEE-84424	Hose	1		
(9)	22-NEE-84521	Hose	1		
(10)	22-NEE-84426	Hose	1		
(11)	22-NEE-84427	Hose	1		
(12)	SBH11120351	Bolt	16		
(13)	WP512	High strength plain washer	16		
(14)	GRAG125	O-ring	4		
(15)	CC0140	Clamp	17		
(16)	2Q-1069-32	Elbow	2		
(17)	2Q-1068-15	Connector	2		
(18)	2Q-1069-1/4-9/16	Elbow	3		
(19)	2Q-4043-12-12	Connector	3		
(20)	2Q-1068-19	Connector	1		
(21)	2Q-1069-19	Elbow	1		
(22)	2P-1009-12-16-N	Connector	1		
(23)	SPB12	Plug	1		

3－1 POWER HYDRAULIC OIL PIPING

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
(54)	HNL0611612	Bushing	2		
(55)	SNH141020	Nut	1		
(56)	2P-2086-16	Elbow	2		
(57)	SBH14100201	Bolt	12		
(58)	SBH14060201	Bolt	1		
(59)	29-2103-01-53.00	Coupling Assy	1		
(60)	SBH14080151	Bolt	2		
(61)	2P-4043-06-04-N	Connector	1		
(62)	SNH140610	Nut	11		
(63)	SNH141210	Nut	4		
(64)	SNH141610	Nut	2		
(65)	HA1504	Adapter	1		
(66)	WS206	Washer, spring	11		
(67)	WS210	Washer, spring	14		
(68)	WS212	Washer, spring	4		
(69)	WS216	Washer, spring	4		
(70)	2P-1036-12-16-N	Elbow(45°)	1		
(71)	HNL0613216	Bushing	2		
(73)	SNH141010	Nut	1		
(74)	HA1512	Adapter	1		
(75)	HNL0911600	Cross	1		
(77)	H05051160310P	Hose	1		
(78)	HNL0521200	Elbow	1		
(79)	H05051161300P	Hose	1		
(80)	H05057042000P	Hose	1		
(81)	SBH14160451	Bolt	4		
(82)	WP112	Washer, plain	4		
(83)	WP116	Washer, plain	6		
(84)	2F-X100-1078	Hose	1		
(85)	2F-X100-1079	Hose	1		

3－2 TRAVELING POWER AND APPARATUS

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～(31)	040-00450-000	Running device group Assy	1		
4	043-1730-001	Shaft, upper	1		
5	304-0910-001	Plate, end	4		
6	314-0170-001	Washer, lock	4		
7	043-0690-001	Cover	2		
8	043-1740-001	Shaft, lower	1		
9	043-2040-001	Cover	1		
10	041-0760-200	Housing	1		
11	044-1830-001	Spacer	2		
12	042-1790-200	Bracket	1		
13	043-2050-101	Flange , yoke	2		
(3)	92-14.00-24-24PR TB	Tire	4		
(4)	3M-W-12856	Wheel, disk	4		
(5)	50-15861-0460	Shaft, propellor	3		
(6)	50-158-000200	Shaft, propellor	1		
(7)	50-158-001140	Shaft, propellor	1		
(8)	08-44621-21280	Flange , yoke	2		
(9)	55-UCFC216D1U	Unit, bearing	2		
(12)	SBH11120552	Bolt	40		
(13)	SBH18140351	Bolt	8		
(14)	SBH14201551	Bolt	4		
(15)	SBH11100251	Bolt	8		
(16)	SLTB080105134	Seal, oil	2		
(17)	JB6214NJ	Bearing	2		
(18)	GRAP55NJ	O-ring	2		
(19)	SPB06	Plug	1		
(20)	SPE08	Plug	1		
(21)	2A-EZ3193A0	Air breather	1		
(22)	WS212	Washer, spring	40		
(23)	WS214	Washer, spring	8		

3−3 PROPELLER SHAFT

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～14	50-15861-0460	Propeller shaft Assy	1		
1	50-5860-0805	Journal Assy	2		
2	50-90903-10060	Nipple, grease	2		
3	*	Bearing,needle	8		
4	*	Spider	2		
5	50-15860-6260	Flange Assy	1		
6	*	Flange	1		
7	*	Plug	1		
8	50-90903-10060	Nipple, grease	1		
9	50-15070-5160	Retainer	1		
10	50-10972-0280	Ring,felt	1		
11	50-5070-981	Ring	1		
12	50-15860-2390	Flange,stub	1		
13	50-99106-62550	Bolt	8		
14	50-90915-05120	Washer, spring	8		

3－4 PROPELLER SHAFT

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～16	50-158-000200	Propeller shaft Assy	1		
1	50-9910662550	Bolt	8		
2	50-9091505120	Washer, spring	8		
3	50-158-000180	Flange Assy	1		
4	*	Flange	1		
5	*	Ring, snap	2		
6	*	Shaft,Splined	1		
7	50-15860-6020	Flange Assy	1		
8	*	Ring,felt	1		
9	*	Retainer	1		
10	*	Flange	1		
11	50-9090310060	Nipple, grease	1		
12	*	Plug	1		
13	50-5860-0805	Journal Assy	2		
14	*	Spider	2		
15	*	Bearing,needle	8		
16	50-9090310060	Nipple, grease	2		

3−5 PROPELLER SHAFT

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～19	50-158-001140	Propeller shaft Assy	1		
1	50-9910662550	Bolt	8		
2	50-9091505120	Washer, spring	8		
3	50-158-001150	Tube Assy	1		
4	*	Flange	1		
5	*	Plug	1		
6	*	Tube	1		
7	*	Shaft	1		
8	50-15860-6020	Flange Assy	1		
9	*	Ring,felt	1		
10	*	Retainer	1		
11	*	Flange	1		
12	50-9090310060	Nipple, grease	1		
13	*	Plug	1		
14	50-5860-0805	Journal Assy	2		
15	*	Spider	2		
16	*	Bearing,needle	8		
17	50-9090310060	Nipple, grease	2		
18	*	Weight,balance	A/R		
19	*	Weight,balance	A/R		

3－6 SUSPENSION

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～(27)	061-0380-400	Suspension group Assy	1		0001
1	614-0250-001	Pin, knock	2		
3	063-0720-001	Pad, spring	2		
6	064-0780-001	Spacer	2		
7	063-0750-101	Seat,contact	2		
8	064-0790-101	Plate	4		
(1)	12-10400-22108..1	Absorber, shock	2		
(2)	3D-9198-08100	Spring, leaf	2		
(2)	39-TLN-03x161	Spring, leaf	2		
(3)	SBA6140301	Bolt,hexagon socket head	4		
(4)	WS414	Washer, spring	4		
(5)	39-TS54215-Z2002	Pin	2		
(6)	00-56165-Z1002	Pin	2		
(7)	39-JB-000927	U-Bolt	4		
(8)	39-363924-15	Nut	8		
(9)	SBH18221601	Bolt	2		
(10)	92-M22p2.5 8T	Nut,hard lock	2		
(11)	00-55241-90000	Rubber, bumper	2		
(12)	LGS02	Nipple, grease	2		
(13)	LGAL02	Nipple, grease	2		
(14)	00-08014-07010	Bolt	2		
(15)	00-08911-14010	Nut	2		
(16)	00-08911-05010	Nut, castle	2		
(17)	00-08911-25010	Nut	2		
(18)	WS220	Washer, spring	2		
(19)	WP120	Washer, plain	2		
(20)	SNH182410	Nut	16		
(21)	WP124	Washer, plain	16		
(23)	PS4040	Pin, split	2		
(24)	SBH14120201	Bolt	4		

3－7 LEAF SPRING

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～15	39-TLN-03x161	Spring Assy, leaf	1		
1	39-012-06112120	Bolt, center	1		
2	39-012-06112121	Bolt, center	1		
3	39-022-3630090	Bushing	1		
4	39-B0-3290061	Clip	2		
5	39-030-10115	Bolt, clip	2		
6	39-030-10116	Nut, clip	2		
7	39-040-10090	Collar	2		
8	39-061-1322	Rivet	2		
9	39-03x161-01	Spring No.1, leaf	1		
10	39-03x161-02	Spring No.2, leaf	1		
11	39-03x161-03	Spring No.3, leaf	1		
12	39-03x161-04	Spring No.4, leaf	1		
13	39-03x161-05	Spring No.5, leaf	1		
14	39-03x161-06	Spring No.6, leaf	1		
15	39-03x161-07	Spring No.7, leaf	1		

3−8 SHOCK ABSORBER

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～8	12-10400-22108..1	Absorber Assy, shock	1		
1	*	Absorber, shock	1		
2	12-10401-90101	Bushing, rubber	1		
3	12-10401-90704	Washer, eye	1		
4	12-10401-90702	Washer, eye	1		
5	12-10401-90301	Washer, center	2		
6	12-10401-90201	Bushing, rubber	2		
7	12-10401-90401	Washer	2		
8	12-10401-90501	Nut	2		

3−9 AXLE

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～49	36-12045-0001..2..1	Axle Assy, front	1		
1～49	36-12045-0002..3..1	Axle Assy, rear	1		
1	36-1981K	Differential Assy	1		
2	36-3111312030	Bolt	8		
3	36-3111312040	Bolt	4		
4	36-3322012	Plate	12		
5	36-12045-2010	Housing,axle	1		
6	36-19600-0121	Breather	1		
7	36-3621106	Plug	1		
8	36-3621206	Plug,magnet	1		
9	36-12045-3320	Shaft, axle	2		
10	36-12022-3090	Spindle	2		
11	36-19110-2490	Bolt	32		
12	36-11818-3110	Spacer,gear	2		
13	36-11858-3080	Gear,sun	2		
14	36-11981-3210	Spider,planetary gear	2		
15	36-11858-3090	Gear,planetary	6		
16	36-11858-3100	Shaft, planetary gear	6		
17	36-11146-1280	Ring,thrust	12		
18	36-19800-0250	Bearing,needle	12		
19	36-19750-1020	O-ring	2		
20	36-3111314045	Bolt	48		
21	36-3312114	Plate	48		
22	36-12045-3270	Cover,spider gear	2		
23	36-19750-0530	O-ring	2		
24	36-3111308020	Bolt	18		
25	36-3321108	Plate	18		
26	36-3621106	Plug	2		
27	36-3621204	Plug,magnet	2		
28	36-11929-3260	Hub,internal gear	2		

3－10 DIFFERENTIAL GEAR

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～39	36-1981K	Differential group Assy	1		
1～4	36-1059A	Carrier Set	1		
1	*	Carrier	1		
2	*	Cap,bearing	2		
3	36-3111316095	Bolt	4		
4	36-19300-0930	Washer	4		
5	36-11059-1270	Nut,ring	2		
6	36-11118-1050	Pin,ring nut lock	2		
7	36-11059-1300	Plug,thrust	1		
8	36-11059-1310	Bolt,thrust	1		
9	36-19200-0150	Nut	1		
10～12	36-1059B	Sim set	1		
10	36-19350-3110	Sim	A/R		t=0.15
11	36-19350-3120	Sim	A/R		t=0.20
12	36-19350-3130	Sim	A/R		t=0.50
13	36-3851030214	Bearing,tapered roller	2		
14,15	36-1981G	Gear,spiral set	1		
14	*	Pinion,spiral bevel	1		
15	*	Gear,spiral bevel	1		
16	36-19110-2301	Bolt	16		
17	36-11059-1100	Cage,pinion bearing	1		
18	36-11059-1070	Distance piece	1		
19	36-11059-1091	Collar,flange	1		
20	36-11059-1110	Case,oil seal	1		
21	36-19200-1070	Nut	1		
22	36-19360-0480	Packing	1		
23	36-19800-0200	Bearing,roller	1		
24	36-3851230310	Bearing,tapered roller	2		
25	36-3131212050	Bolt	6		
26	36-3322012	Washer	6		

3-11 BRAKE CALIPER (Front)

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～13	36-11981-5030	Caliper Assy(front·right)	1		
1～13	36-11981-5040	Caliper Assy(front·left)	1		
1	36-84-35	Valve,bleeder	1		
2	36-43-1140	Bolt	3		
3	36-43-2080	Bolt	1		
4	36-20-2015	Torque pin	2		
5	36-20-2014	Torque pin	2		
6	36-68J1161	O-ring	4		
7	36-304-2601	Lining pad set	1		
8	36-43-1189	Bolt,cap	8		
9	36-93-2080	Cover plate	1		
10	36-49-2008	Plug,piston	3		
11	36-306-2024	Seal kit	1		
12	36-74-2004	Piston	6		
13	36-324-2001	Cap,bleeder	1		

3-12 BRAKE CALIPER (Rear)

Serial No. 0001 Only

Illust No.	Part No.	Part Name	QTY	CONV	Remarks
1～14	36-11981-5010	Caliper Assy(rear·left)	1		
1～14	36-11981-5020	Caliper Assy(rear·right)	1		
1	36-84-35	Valve,bleeder	1		
2	36-43-1140	Bolt	2		
3	36-43-1196	Bolt	2		
4	36-20-2015	Torque pin	2		
5	36-20-2014	Torque pin	2		
6	36-68J1161	O-ring	4		
7	36-304-2401	Lining pad set	1		
8	36-43J1184	Bolt,cap	2		
9	36-43J1189	Bolt,cap	4		
10	36-93-2005	Cover plate	1		
11	36-49-2008	Plug,piston	2		
12	36-306-2009	Seal kit	1		
13	36-74-2004	Piston	4		
14	36-324-2001	Cap,bleeder	1		